

## Installation Instructions JLT Brake Cooling Kit (2007-09 Shelby GT500) #JLTBCK-GT500

Thank you for purchasing our product. Take your time and it will be a smooth install.

## Please review complete instructions prior to installing.

Step#	
1	Verify you have all of the following parts included in the kit: (2) JLT backing plates, (2) Brake hoses, (4) #40 Hose Clamps, (6) Zip ties Optional: JLT Grille Bezels
2	Gather all of the following tools needed for the installation: Jack, jack stands, lug wrench, 5/16 or 8mm nut driver, 15mm socket, 10mm socket and ratchet, angle drill, 2 ¼" hole saw
3	Jack car up and secure on jack stands
4	Remove both front wheels
5	Remove (2) 15mm bolts and remove brake caliper

Remove stock backing plates (3 10mm bolts) Replace with JLT backing plates using 2 bolts. You can put 3<sup>rd</sup> back in hole and tighten or save it.





Page 1 of 3 04-02-09

7 Driver side only, remove stock shield seen here. It is held on by 3 clips



Using your drill and the 2 ¼" hole saw, drill from the back side of the bumper through the grille. Using a small angle drill or flexible extension will help. You can remove the bumper if you do not have the angle drill. You can also use a small air ratchet and socket if your hole saw has a hex shaft. See picture. If you purchased the JLT Bezels snap them in now.





9 Put the clamps on the hose ends, install on bumper mount and tighten



Page 2 of 3 04-02-09

10 Attach other end to JLT backing plates and secure hose to frame loop and sway bar with Zip ties as shown





Repeat process for opposite side and check clearance between the hose and tire.

12



Reassemble brakes and wheels in reverse and you are done. Don't forget to re torque your lug nuts after a few miles of driving. We suggest 100 ft lbs.

Thanks for the business. If you have any questions, please e-mail  $\underline{\text{Jay@JLTtruecoldair.com}}$  or call 757-335-1940. Our hours are 8:00am - 5:00pm Eastern Time.

Warranty: JLT Performance Inc. will repair or replace any part of their product found upon our inspection to be defective in workmanship or material within 1 year from the purchase date for the original purchaser.

<u>Disclaimer:</u> JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.

disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.

<u>Custom Paint Disclaimer</u>: All custom paint jobs are done by JLT Performance Inc. Every job is different and done by hand. By ordering a custom paint job, you accept this fact and cannot hold JLT Performance liable for the end result not being exactly what you had in your mind.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Air Filters will not be accepted for return unless they are in original plastic sealed bag. Please visit <a href="www.JLTtruecoldair.com">www.JLTtruecoldair.com</a> for complete return policy.

Page 3 of 3 04-02-09